

UPC 500 MAX & MAX PRO

TECHNICAL DATA SHEET & SPRAY GUIDELINES

ULTRA-HIGH YIELD
CCRR-0358



UPC 500 MAX OPEN-CELL FOAM

UPC 500 Max is a two component, water blown (zero ozone depleting chemical) light density, open cell spray polyurethane foam insulation that is designed to improve the performance of the building envelope for commercial, residential and industrial applications.

Physical Properties					
Core Density	ASTM D1622	0.45 pcf ± 0.05	Tensile Strength	ASTM D1623	5 psi
R-Value @ 1”	ASTM C518	3.8	Air Permeance @ 3.5”	ASTM E2178 @ 75 PA	0.00431
Water Vapor Permeance	ASTM E96	9 Perms	Dimensional Stability	ASTM D2126	< 14.7%
Intertek Certified Clean Air Gold: Conforms to California Department of Public Health (CDPH) Standard Method v1.2: Private Office and School Classroom				CDPH 01350 v1.2: PO, SC, R for VOC emissions and formaldehyde	
Liquid Properties		A-PMDI Isocyanate		UPC 500 Max Resin	
Color		Brown		Amber	
Viscosity (Brookfield cps) @ 77°F		200 ± 30		360 ± 100	
Specific Gravity		1.24		1.07	
Mixing Ratio (volume)		1:1		1:1	
Fire Test Results					
Flammability		ASTM E84 @ 4”		15 Flame Spread 200 Smoke Development	
Large Scale Fire Testing: Ignition Barrier		AC 377 Appendix X*		PASS: 6 Wet Mils DC 315	
Large Scale Fire Testing: Thermal Barrier		NFPA 286*		PASS: 18 Wet Mils DC 315 14 Wet Mils No-Burn	
Alternative Unvented Attic Assembly*: End Use Configuration Testing		Conforming to IBC Section 1202.3 or IRC Section R806.5		Approved for certain attics without a prescriptive ignition barrier or intumescent coating*	
NFPA 259		1,796 Btu/ft² @ 3.5”		NFPA 285	PASS
Reactivity Profile					
Cream Time	1-2 seconds	Gel Time	3-4 seconds	Tack Free	6-7 seconds
				End of Rise	6-7 seconds

*See Intertek CCRR-0358 for additional instructions or consult with UPC's Technical Department for details: 203-760-0025

SPRAY PARAMETERS

This chart is a **starting guide** to set temperatures based on environment, mixing chamber size. Adjustments should be made to account for substrate temp/type, hose insulation condition, speed of sprayer, wind factor, etc. A smaller mixing chamber, like a 4242, will give you the best quality foam at optimal speed-to-yield ratio.

Select Mixing Chamber:	4242 -01			5252 -02			6060 -03			
Select Ambient Temp and Match to Mix Chamber	Temperature Set			Temperature Set			Temperature Set			
	Hose ₁	A	B	Hose ₁	A	B	Hose ₁	A	B	
Substrate Temperature for standard wood (Starting Drum Temperature Must be Minimum of 75 °F)	> 90°F	113°F	116°F	119°F	114°F	117°F	120°F	115°F	118°F	121°F
	80°F	115°F	118°F	121°F	116°F	119°F	122°F	117°F	120°F	123°F
	70°F	118°F	121°F	124°F	119°F	122°F	125°F	120°F	123°F	126°F
	60°F	122°F	125°F	128°F	123°F	126°F	129°F	124°F	127°F	130°F
	50°F	126°F	129°F	132°F	127°F	130°F	133°F	128°F	131°F	134°F
	40°F	130°F	133°F	136°F	131°F	134°F	137°F	Not Recommended		
	CAUTION: Below 35°F a 1/8"-1/4" initial flashing layer may be applied to substrate to eliminate voids in cold weather.									
	30°F	134°F	137°F	140°F	17,000 bf			Not Recommended		
	20°F	138°F	141°F	144°F						
	15°F	140°F	143°F	146°F						
	10°F	142°F	145°F	148°F						
	< 0°F	Not Recommended								
Pressure Setting	1200 +/- psi			1200-1400 +/- psi			1300-1400 +/- psi			

For UPC 500 Max Pro: Add 7°F to All Suggested Starting Temps

*Important notice regarding yield and density. Many factors affect yield, including substrate temperature, substrate type, and pass thickness. Multiple passes will significantly reduce yield. Larger mixing chamber sizes and higher pressure settings will also reduce yield.

PROCESSING INSTRUCTIONS - Read Carefully

Agitation	Agitation not required, but for optimal performance or older drum, we recommend high speed for 20-30 mins prior to spraying. Color should change from clear to "creamy". Agitation not needed during application. Recommended: Graco collapsing blade Agitator #24C728 or #26C150.
Drum Temperatures & Recirculation	Recirculate as needed to achieve chemical temperatures in the drums of 80°F-95°F for both the A & B-drums (this is necessary to bring viscosities of A&B in alignment to prevent off-ratio foam and increase yield). When recirculating, set the primary heater for the A-Side to 100°F and B-Side to 130°F. Use laser thermometer or inlet temp gauge to measure drum temp (A-Drum should NEVER be warmer than B-Drum).
Substrate Condition	Substrate must be clean, dry, and moisture content <19%. Substrate temp should be >5°F above dew point. When substrate temperature is below 45°F, pre-heat building. When heating with portable heaters, if concrete or metal substrate only heat to 50°F, otherwise condensation may form. Never use portable propane heaters.
Spray Technique	Spray side-to-side approx 18" from surface recommended. The further away you spray, the colder the chemical will be when reaching substrate, and potential for voids. Reverse picture frame technique is also suggested if desired.
Humidity	When humidity levels exceed 50% and temperatures are below 85°F, reduce the A-Side temperature by 5°F +/- to reduce Iso reactivity/blowbacks.
Contamination	B-Side is sensitive to contamination from other products. Never recirculate another product into the UPC 500 MAX. Never combine different products. Transfer pumps must be properly cleaned between product. Recirculating lines must be properly flushed before recirculating.
Max Min Pass Thickness	Max practical pass thickness is 6" (10" for Max Pro) before splash-back. Min recommended pass thickness is 3", except when flash-coat needed.
Proper Temperature Settings	As a general rule of thumb, the hose temperature is the most important setting and should be set first. The A-side is set 2-5°F higher than the hose. The B-Side is set 3-10°F higher than the A-Side depending on humidity levels.

PROCESSING INSTRUCTIONS *(continued)*

† Heated Hose	A poorly insulated hose may not be able to maintain adequate hose heat and drastically change required temp settings on primary heaters. Never increase hose temp above 145°F - you can burn the hose. If using Graco's Resistance Control Mode, consult UPC tech support for guidance.
Maximizing Yield	Dozens of factors affect yield, but properly dialing in temps has the biggest impact. For open-cell, start temperatures hot enough that the foam shrinks slightly from the studs, then lower temps 3°F at a time until shrinkage stops - this is the yield sweet spot.
**Pressure Settings	Higher fluid pressure settings create more mist and require greater distance from the cavity, resulting in more overspray. Higher pressure will generally lower yield. As a rule-of-thumb, you should practice spraying as close to 1000psi as practical.

TROUBLESHOOTING GUIDE

Delamination or "Swiss Cheese" Cell Structure	If the foam does not adhere to itself or "swiss cheese" cell structure on 2nd layer, then allow first layer to cool off before applying 2nd pass. This may be caused by trapped steam between layers. If void between foam & substrate, but not "stringy" (known as a "blowback") follow same procedure.
Pulls Away From Studs or Deflates	If pulls away or "shrinks" from studs within a few seconds, then foam is too hot. Lower primary heaters and hose temperatures by 3°F. Spray out chemical in hose (approx 2-3 gallons) until reduced temp is achieved. If problem does not resolve, lower temp by another 3°F, and repeat process until resolved. If foam pulls away from studs several minutes after application, then chemical may be contaminated.
Voids behind foam	If stringy like hairs between the substrate and foam ("coconut hairs" texture), the foam may be too cold. Increase all heaters by 5°F. Spray out chemical in hose (approx 2-3 gallons) until new increased temperature is achieved. Repeat process until problem is resolved.
Voids & Shrinking	If foam creates voids and shrinks from studs at the same time, then increase B-side drum temp only to 100°F. Machine ΔT may be too low.
Beehive Cell Structure	If the foam has consistently large cell structure, like a "beehive", then the foam may be too cold. Increase all heaters by at least 10°F to 15°F. If problem persists, chemical may be contaminated.
Color	If the foam appears yellowish or "marbling", then it is too cold. Primary heaters should be increased 3 to 5°F. Should appear "white".
Crunchy or Gummy	If foam is crunchy and amber in color, then foam may be Iso rich and off-ratio. If "gummy" consistency, then foam may be Resin rich. Check equipment.
Poor Yield	Check temp settings. If temperatures are dialed-in too cold, then lack of heat will generate poor chemical reactivity & poor yield (See "Drum Temperatures" & "Maximizing Yield" under Processing Instructions). B-Side may not be thoroughly mixed, may need agitating. Check chemical expiration.
Important	Regardless of proportioner heating capacity, never spray from cold drum chemical. Powerful primary heaters may scorch B-side polyols. Follow "Drum Temperatures & Recirculation" procedures under Processing Instructions.

Cautions and Recommendations:

UPC 500 Max is not designed for use as an exterior roofing system. UPC 500 Max is designed for installation in most standard construction configurations using common materials such as, concrete, metal, and wood products. Foam plastic installed in walls or ceilings may present a fire hazard unless protected by an approved, fire-resistant thermal barrier with a finish rating of not less than 15 minutes as required by building codes. Rim joists/header areas in accordance with the IRC® and IBC®, may not require additional protection. Foam plastic must also be protected against ignition by code-approved materials in attics and crawl spaces, or as code approved alternatives apply.

As with all SPF systems, improper application techniques should be avoided and any defective product replaced with properly installed materials. Examples of improper application techniques include but are not limited to, excessive application thickness, off-ratio material and spraying into or under rising liquid foam. Additionally, off-ratio materials can result in offensive odors that may not dissipate. It is the responsibility of the applicator to understand how their equipment works.

Job-site Warnings:

Applicators should ensure the safety of the job-site and construction personnel. SPF Insulation is combustible and appropriate signs shall be posted warning that all "hot work" such as welding, soldering, and cutting with torches should not take place until a thermal barrier or approved equivalent is installed over any exposed polyurethane foam.

Contractors should communicate with other trades working in proximity to the spray application area. Appropriate warning signs at each entryway must be posted that clearly indicates that spray foam activity is taking place and proper respiratory protection is required to enter. Non SPF personnel and occupants should be vacated from the building during the application of SPF. Proper Ventilation during spraying and afterwards at minimum 10 Air changes per hour. **Re-Entry:** Ventilate for 2 hours before personal protective equipment is no longer required for trades and inspectors. **Re-Occupancy:** After 24 hours of continuous ventilation, building may be re-occupied.

Health and Safety Information:

Before working with this product, you must read and become familiar with available information (e.g., Safety Data Sheet (SDS)) on its risks, proper use and safe handling. All contractors and applicators must use appropriate respiratory, skin and eye Personal Protective Equipment (PPE) when handling and processing spray foam systems.

Refer to the Center for the Polyurethanes Industries (CPI): "Guidance for Developing a Written Respiratory Protection Program", "Guidance on Best Practices for the Installation of Spray Polyurethane Foam", and "Spray Polyurethane Foam Product Stewardship Guidance". Available at www.spraypolyurethane.org and www.UPCFoam.com

Shelf Life and Storage:

UPC 500 Max has a shelf life of approximately six months from the date of manufacture when stored in original, unopened containers at 50-80°F. This material should be stored in a secure location and never in direct sunlight. Storage temperatures above the recommended range will shorten shelf life.

Vapor Retarder:

UPC 500 Max is intended for indoor applications, and is not a vapor retarder. It is vapor permeable and will allow for some diffusion of moisture through the insulation. The following considerations are needed:

- (1) A vapor retarder needs to be considered in the design of the building envelope in cold climates, such as zones 4 and higher in the U.S., as defined in 2004 Supplement to the IRC®, Table N 1101.2;
- (2) A vapor retarder also needs to be considered where high interior humidity conditions exist.



DISCLAIMER: Please read all information in the general guidelines, technical data sheets, application guide and safety data sheets (SDS) before applying material. UPC products are for Professional Use only and preferably applied by professionals who have prior experience with the UPC products or have undergone training in application of UPC products. Published Technical data and instructions are subject to change without notice. Contact your local Universal Polymers representative or visit our website for current technical data and instructions. All guidelines, recommendations, statements, and technical data contained herein are based on information and tests we believe to be reliable and correct, but accuracy and completeness of said tests are not guaranteed and are not to be construed as a warranty, either expressed or implied. It is the user's responsibility to satisfy himself, by his own information and tests, to determine suitability of the product for his own intended use, application and job situation and user assumes all risk and liability resulting from his own use of the product. We do not suggest or guarantee that any hazards listed herein are the only ones that may exist. Neither seller nor manufacturer shall be liable to the buyer or any third party for any injury, loss or damage directly or indirectly resulting from use of, or inability to use, the product. Recommendations or statements, whether verbal or in writing, other than those contained herein shall not be binding upon the manufacturer, unless in writing and signed by a corporate officer of the manufacturer. Technical and application information is provided for establishing a general profile of the material and proper application procedures. Test performance results were obtained in a controlled environment and Universal Polymers makes no claim that these tests or any other tests, accurately represent all environments. UPC is not responsible for typographical errors.